

# Roofdrain

## General Advice

These instructions should be read in conjunction with the contract specification and drawings. They are intended to provide guidance in normal installation situations and are addressed to the installer on site. If there are any questions related to the design, unusual installation challenges, or any doubt, consult ABG for further advice. In all situations, responsibility for installation remains with the Installer.

## Description

**Roofdrain** is a geocomposite roof drainage and water reservoir layer. It's always laid with the cup shapes facing upwards to collect water, enabling water storage for hydration of plants. To achieve this, the **Roofdrain** must be turned over after un-rolling. The void on the underside between the cusps, transmits excess rainwater away. Its main application is in a lightweight, extensive flat roof construction. (Fig. 1).

**Roofdrain** is available in four formats (Fig. 2):

- 1) **SS.** Sheet form comprising a perforated cusped HDPE core with a lightweight filter geotextile bonded to the flat side and with a second (usually heavier) geotextile bonded to the cusped side of the core.
- 2) **T.** Sheet form comprising a perforated cusped HDPE core with a lightweight filter geotextile bonded to the flat side.
- 3) **T.** Sheet form comprising a perforated cusped HDPE core (usually 60mm thickness)
- 4) **W.** Narrow widths of perforated HDPE core fully wrapped in geotextile.


## Supply

**Roofdrain** is supplied wrapped in UV light-proof wrap that should only be removed just before installation.

**Roofdrain** can be carried or rolled, but should not be dragged. Rolls should be harnessed when lifted by crane. Rolls are typically 1.3m in diameter x 0.9m wide & weigh approx. 75 kg. (Fig. 3).



**Fig. 1: Roofdrain roof drainage geocomposite, light filter geotextile on the flat side and heavier geotextile on the cusped side of the core.**



**Fig. 2: Four different Roofdrain formats available.**



**Fig. 3: Roofdrain is supplied in a UV light-proof wrap, to be removed just before installation. Typically 1.3m in diameter x 0.9m wide.**


# Roofdrain

---

## Equipment Required (Fig. 4).

---

- Safety knife
- Sand bags or fill material for ballasting
- Jointing tape
- **Terrex** geotextile strip



**Fig. 4: Equipment required.**

---

## Installation guidance

---

### Step 1

**Roofdrain** is laid with the flat side facing up (with the holes in the core at the top), ready to receive the soil backfill. The cusped side is laid against the roof's waterproofing. (Fig. 5).

In choosing the commencing point and direction of laying, consider the intended access point for placing backfill material to avoid any unnecessary need to traffic over the **Roofdrain**.



**Fig. 5: Lay with geotextile filter & cusped openings facing up.**

---

### Step 2

**Roofdrain** is supplied in strips of the appropriate width when used on standing seam metal roof systems and the strips are simply unrolled into position, cut to length and turned over. (Fig. 6).



**Fig. 6: Manufactured to the appropriate width for use on standing seam metal roof systems.**

---

### Step 3

**Roofdrain** will unroll with the flat side facing down, so the rolls must be turned over before laying.

---

### Step 4


Put the first roll of **Roofdrain** into position such that the geotextile flaps lap up onto a side wall. Rolls can be cut to length with a safety knife. The flap can be held in position with mastic or jointing tape.

# Roofdrain

## Step 5

The adjacent roll is placed such that the cores butt together. The geotextile flap overlaps the adjacent sheet.

Installation continues to the far wall where a Terrex 300-500mm wide geotextile strip is used to flap over the core and up to the wall. If necessary, the textile strip can be held in place temporarily with jointing tape. (Fig. 7).



**Fig. 7: Butt rolls together with overlap and lap geotextile flap up edges / walls.**

## Step 6


On gently sloping roofs, the **Roofdrain** must be a continuous length over the apex of the roof with equal lengths both sides, otherwise an anchorage must be provided at the apex of the roof. (Fig. 8).



**Fig. 8: Roofdrain installed to gently sloping roof, anchored at the apex.**

## Step 7

On steeply sloping roofs, a high strength geogrid such as **Trigrid** will be required above the **Roofdrain** to transmit the forces back to an anchorage point. (Fig. 9).



**Fig. 9: Roofdrain installed to steep roofs (additional Trigrid layer shown for anchoring in place).**

## Step 8


When a **Roofdrain** with no 'upper' geotextile is used, large cups are filled with **Leca** or gravel before a non-woven geotextile is laid over the whole area.

## Step 9

Sand bags or similar must be used as ballast to hold the **Roofdrain** in place in windy conditions.

## Step 10

**Roofdrain** can be cut and sealed around columns and other roof slab penetrations. (Fig. 10).




**Fig. 10: Roofdrain cut around penetrations (e.g. vent chimney & roof light).**

# Roofdrain

## Step 11

Non-load bearing walls and planters can be built off **Roofdrain** by providing a concrete pad that limits the compressive stress to 50 kPa. Otherwise, the cusps must first be filled with mortar. To do this the geotextile must be cut at one side, peeled back and mortar hand placed into the cusps, taking care that mortar does not fall through the holes in the core. Finally the geotextile is replaced and the wall construction can commence. (Fig. 11).



**Fig. 11: Roofdrain can be filled with mortar for construction of non-load bearing walls and beneath planters.**

## Step 12

Before backfilling, inspect the installation to make sure that there are no gaps in the geotextile where soil can enter the core. Ensure that water can exit freely from the **Roofdrain** if the outlets are along the ends or sides.

Backfill with good quality growing media for planted areas or sand for feature paved pedestrian areas. (Fig. 12).

At least 150mm of temporary backfill material should be maintained over the **Roofdrain** where mechanical plant is working. Temporary access routes over **Roofdrain** for mechanical plant should be protected with boards.



**Fig. 12: Backfill with growing media (planted areas) or sand (paved areas).**

## Step 13

On steeply sloping roofs, the growing media may require containment in a geocell such as **Erosaweb GWX**.

## Step 14

If the **Roofdrain** geotextile cover is damaged, small areas can be repaired using a patch of similar textile at least 300mm larger than the damaged area. Damaged drainage core is cut out locally and a similar shaped replacement is inserted.

Standard **Roofdrain** geotextile cover is damaged, small areas can be repaired using a patch of similar textile at least 300mm larger than the damaged area. Damaged drainage core is cut out locally and a similar shaped replacement is inserted. (Fig. 13).



**Fig. 13: Replacing a section of damaged core.**

# Roofdrain

---

## Notes

---

- 1) Do not drive directly on the Roofdrain
- 2) Avoid prolonged time between laying Roofdrain and back-filling so as to reduce the risk of wind damage
- 3) Place growing media evenly
- 4) Interface shear strength is key on very steep roofs. Seek technical advice.
- 5) Collect all off-cuts and disperse safely.
- 6) There are no known COSHH hazards associated with the installation of Roofdrain. Download MSDS @: <http://www.abg-geosynthetics.com/request-file.act?target=582>

---

## Terms and Conditions

---

Site specific engineering design should be carried out after site investigation has provided all the necessary information.

The assessment of suitable safety factors in relation to each particular project must always remain the responsibility of the design engineer.